EN W08015 LED lighting with remote control Floco



Dear customer, thank you for purchasing our product. Please read the following instructions carefully and follow them to serve you safely and to your full satisfaction. This will prevent misuse or damage. Avoid unprofessional handling of this appliance and always observe the electrical appliance usage guidelines. Do not hang or cover the luminaire with anything. Keep the instruction manual carefully. Installation must only be carried out by qualified personnel.


TECHNICAL PARAMETERS

	W 0 8 0 1 5
Voltage	220-240V AC
Consumption	max. 30W + 6W RGB
Luminous flux	max. 2100lm
Chromaticity	3000K - 6500K
Coverage	IP20
LED lifetime	20.000 hours
Dimensions	395 x 80 mm
Operating temperature	-20°C to 50°C

INSTALLATION


Switch off the power supply before installation!

- 1. Insert the dowels into the pre-drilled holes.
- Remove the rear of the luminaire by turning it and thread the supply cable through the hole in the rear of the luminaire.
- 3. Drill the back of the luminaire.
- Connect the supply cable to the terminal block and make sure that the connection is correct.
- 5. Rotate to attach the front of the luminaire to the rear.
- 6. Switch on the power supply.



REMOTE CONTROLLER

- 1. On
- Off
- 3. Brightness +
- 4. Brightness -
- 5. Colour temperature of light -
- 6. Colour temperature of light +
- 7. Light color: 3000K/4000K/6500K
- 8. RGB color selection (13 options)
- 9. RGB color change (13 options)
- 10. Short Press: Night Light
 Long press: Timer (turns off after 1 min.)
- 11. Stop/Play RGB color change mode
- 12. Short press: increase RGB color change speed Long press: decrease RGB color change speed



The light source of this luminaire is non-replaceable, at the end of its service life the entire luminaire must be replaced and disposed of in a designated place. This product contains a light source that for design reasons cannot be removed for verification and therefore the entire product is considered a light source. The manufacturer is not liable for any damage caused by improper use.

The product has been issued with a CE declaration of conformity in accordance with the applicable regulations. On request from the manufacturer: info@solight.cz, or downloadable from www.solight.cz/en.



